



KEYBOARD COMMANDS

SIMULATOR	
Pause	F12 or P
Sound (on/off)	Q
Flying Tips (display/hide)	CTRL + SHIFT + X
Capture Screenshot	V
End Flight	ESC
Menus	ALT (hold to turn off)
Kneeboard	F8
Cycle Kneeboard	SHIFT + F10
Save Flight	F11

LIGHTS	
Lights - all (on/off)	L
Strobe Lights (on/off)	O
Panel Lights (on/off)	SHIFT + L
Landing Lights (on/off)	F2
Landing Light (tilt down)	CTRL + SHIFT + Num Pad 2
Landing Light (tilt left)	CTRL + SHIFT + Num Pad 4
Landing Light (tilt right)	CTRL + SHIFT + Num Pad 6
Landing Light (tilt up)	CTRL + SHIFT + Num Pad 8
Landing Light (tilt center)	CTRL + SHIFT + Num Pad 5

AUTOPILOT	
Master (on/off)	Z
Flight Director (on/off)	CTRL + F
Wing Leveler (on/off)	CTRL + V
Yaw Damper (on/off)	CTRL + D
Altitude Hold (on/off)	CTRL + Z
Altitude Bug (select)	CTRL + SHIFT + Z
Heading Hold (on/off)	CTRL + H
Heading Bug (select)	CTRL + SHIFT + H
Airspeed Hold (on/off)	CTRL + R
Mach Hold (on/off)	CTRL + M
Auto-throttle (arm)	SHIFT + R
Auto-throttle Engage (TOGA)	CTRL + SHIFT + G
NAV Mode (on/off)	CTRL + N
Approach Mode (on/off)	CTRL + A
Back Course Mode (on/off)	CTRL + B
Localizer Hold (on/off)	CTRL + O
Altitude Hold (on/off)	CTRL + T
Increase Selection	= (EQUAL SIGN)
Increase Selection Slightly	SHIFT + = (EQUAL SIGN)
Decrease Selection	- (MINUS SIGN)
Decrease Selection Slightly	SHIFT + - (MINUS SIGN)
Auto-Rudder	SHIFT + CTRL + U

VIEWS	
2-D Cockpit (cycle panels)	F6
View (next category)	S
View (previous category)	SHIFT + S
View (next view in category)	A
View (previous view in category)	SHIFT + A
View (previous view toggle)	CTRL + S
View (default zoom)	BACKSPACE
Look (pan)	ARROW KEYS
Look Forward	F3
Cockpit View	F4
Default View	F5
Cycle Default	F6
Outside View	F7
2-D Panel Transparency	CTRL + SHIFT + T (= or -)
Zoom In	= (EQUAL SIGN)
Zoom Out	- (HYPHEN)
View (next window)	CTRL + TAB
View (previous window)	CTRL + SHIFT + TAB

GENERAL	
Brake (set parking)	F9
Brakes (apply/release)	F10
Landing Gear (extend/retract)	F1
Tail Wheel (lock/unlock)	SHIFT + G
Landing Gear (extend manually)	CTRL + G
Sub-panels (display/hide)	SHIFT + 1 through 9
Cowl Flaps (open incrementally)	CTRL + SHIFT + V
Cowl Flaps (close incrementally)	CTRL + SHIFT + C
Rudder Left	INS
Rudder Right	DEL
Increase Selection	= (EQUAL SIGN)
Increase Selection Slightly	SHIFT + = (EQUAL SIGN)
Decrease Selection	- (MINUS SIGN)
Decrease Selection Slightly	SHIFT + - (MINUS SIGN)

RADIO	
ATC Window (display/hide)	` ACCENT OR SCROLL LOCK
VOR 1 Ident (on/off)	CTRL + 1
VOR 2 Ident (on/off)	CTRL + 2
MKR Ident (on/off)	CTRL + 3
DME Ident (on/off)	CTRL + 4
ADF Ident (on/off)	CTRL + 5
COM Radio (select)	C
NAV Radio (select)	N
OBS Indicator (select)	SHIFT + V
ADF (select)	CTRL + SHIFT + A
DME (select)	F
Transponder (select)	T

INSTRUMENTS	
Heading Indicator (reset)	D
Altimeter (reset)	B
Pilot Heat (on/off)	SHIFT + H

ENGINE	
Select Engine	E + engine number (1-4)
Select All Engines	E + 1 + 2 + 3 + 4
Engine Autostart	CTRL + E
Propeller (low RPM)	CTRL + F1
Propeller (decrease RPM)	CTRL + F2
Propeller (increase RPM)	CTRL + F3
Propeller (high RPM)	CTRL + F4
Carb Heat/Engine Anti-ice (on/off)	H